

Model 12200A RCN
PTAC/PTHP/FAN COIL CONTROL NODE OPERATION

OUTPUTS

G1 = FAN 1 (Low)
O/B = Rev Valve

G2 = FAN 2 (Med)
W = HEAT

G3 = FAN 3 (High)
Y = COMPRESSOR

Operating Modes Summary (Refer to Logic Tables 1 – 5):

1. **PTAC (Standard)** — Fan will Speed-Hunt[†] in AUTO. Fan speed 1*, 2 or 3 may be selected to run the fan continuously at that speed. 'Y' terminal drives compressor. 3-minute short-cycle delay and minimum runtime active on Y terminal*.
2. **PTAC (Energy Saver)** — Fan will Speed-Hunt[†] in AUTO. Fan runs only when heating or cooling. Manually selecting fan speed 1, 2 or 3 will cycle the fan with each call for heating or cooling at that speed. Y terminal drives compressor. 3-minute short-cycle delay and minimum runtime active on Y terminal.
3. **PTHP (Heat Pump)** — Fan will Speed-Hunt[†] in AUTO. Fan speed 1*, 2 or 3 may be selected to run the fan continuously at that speed. Y terminal drives compressor, O/B terminal drives reversing valve. 3-minute short-cycle delay and minimum runtime active on Y terminal*.
4. **FAN COIL (Without Flow Valve)** — Fan will Speed-Hunt[†] in AUTO. Fan runs only when heating or cooling. Manually selecting fan speed 1, 2 or 3 will cycle the fan with each call for heating or cooling at that speed. Y and W are not connected.
5. **FAN COIL (With Flow Valves)** — Fan will Speed-Hunt[†] in AUTO. Fan speed 1*, 2 or 3 may be selected to run the fan continuously at that speed. Use Y to drive the cooling valve, W drives heating valve. 3-minute short-cycle delay on 'Y' terminal is not enforced in this control configuration.

COOLING:

If Temperature is ≥ 1 °F above set point, Y is active. O/B terminal is active only in heat pump mode (discussed later). In FAN COIL mode, Y is used to operate the cooling flow valve.

HEATING:

If Temperature is ≥ 1 °F below set point, W is active. In heat pump mode Y is 1st stage heat, W is Aux / 2nd stage heating brought on when temperature is ≥ 2 ° below set point.

HEAT PUMP:

Mode = COOL and temperature is ≥ 1 °F above set point, Y is active. Mode = HEAT and temperature is ≥ 1 °F below set point Y is active 1st stage heat — 2nd stage heat (W) is active if temperature is ≥ 2 °F below set point. Selectable O or B reversing valve logic (discussed later). O logic = active with Y when in call for cooling. B logic* = active with Y when in call for heating.

COMPRESSOR SHORT CYCLE PROTECTION DELAY:

The Y terminal remains off / delays 3-minutes from last cooling (or heating cycle in heat pump mode) and upon power-up*. In heat pump mode, 2nd stage Aux heat (W) is also delayed with Y. Short-cycle delay can be eliminated in Configuration Setup. (Refer to Configuration Table 2 below.)

MINIMUM COMPRESSOR RUNTIME:

Short cycling due to sudden temperature changes is not permitted. Once called on, the Y terminal will remain active for a minimum of 3-minutes unless the user manually ends a call for cooling (or heating in heat pump mode) by changing the thermostat set point temperature or mode of operation. In heat pump mode, 2nd stage Aux heat (W) also observes the minimum runtime rule.

* Factory default setting.

† Fan Speed-Hunt is a Fan Auto function that automatically sets the fan speed based on departure from the setpoint temperature. E.g., 1° from setpoint = Fan 1, 2° from setpoint = Fan 2, 3° from setpoint = Fan 3.

CONFIGURATION SETUP:

The 12200A control node may require configuration changes before first operation depending on your application. Six configuration property tables guide the user to: 1.) set Mode of Operation, 2.) set compressor Short-Cycle delay ON or OFF, 3.) set Fan Speed, 4.) set Occupancy Mode, 5.) set Occupancy Timeout Delay, 6.) set Reversing Valve Logic. The configuration tables provide operational descriptions and factory default settings. Selections are indicated through the FLASH-COUNT of LED's D3 and D4. (Refer to Figure 1 at the end of this document.) D4 flashes 1 to 6 times to indicate the property table, D3 flashes as many as 6 times to indicate the configuration or 'option' selected.

Referring to Figure 1, PB3 (Reset/Link button) switches the unit into or out of 'configuration' state, PB1 (Mode) selects which Property Table 1, 2, 3, 4, 5 or 6 is indicated by D4 FLASH-COUNT and PB2 (CLEAR) selects the option configuration as indicated by D3 FLASH-COUNT. **Pressing PB2 changes configuration of the RCN.** To review the current setup or change the configuration, refer to the tables below for descriptions and perform the following:

1. If any device such as an occupancy sensor or door switch is wired to the J1 terminals, pull the terminal block off of the board before proceeding.
2. Press and hold PB3 until LED indicator lamps D4 & D3 flash alternately. (*NOTE: At any time during the setup process PB3 can be pressed again to return to normal operation.*)
3. D4 will flash once indicating Table 1, Operating Mode, followed by D3 flashing 1 to 5 times indicating the option configuration in Table 1 that is currently active. (*NOTE: D4 and D3 will flash repeatedly to indicate the Table and the configuration.*) Pressing PB2 will advance the configuration value by one. Press PB2 until the FLASH-COUNT corresponds to the desired configuration. (*Refer to Table 1.*)
4. Press PB1 to advance to Table 2, Short-cycle configuration, as indicated by D4 flashing 2 times, followed by D3 flashing 1 or 2 times. There are only two choices for table 2, PB2 will toggle between them. Press PB2 until the FLASH-COUNT corresponds to the desired configuration.
5. Press PB1 to advance to Table 3, Fan Speed configuration, as indicated by D4 flashing 3 times followed by D3 flashing 1, 2 or 3 times. Pressing PB2 will advance the configuration by one. Press PB2 until the FLASH-COUNT corresponds to the desired configuration.
6. Press PB1 to advance to Table 4, Occupancy Mode configuration, as indicated by D4 flashing 4 times. Pressing PB2 will advance the configuration value by one. (Refer to tables 4-1 and 4-2.) Press PB2 until the FLASH-COUNT corresponds to the desired configuration.
7. Press PB1 to advance to Table 5, Occupancy Timeout Delay configuration, as indicated by D4 flashing 5 times followed by D3 flashing 1 to 6 times. Pressing PB2 will advance the configuration value by one. Press PB2 until the FLASH-COUNT corresponds to the desired configuration.
8. Press PB1 to advance to Table 6, Reversing Valve Logic configuration, as indicated by D4 flashing 6 times followed by D3 flashing 1 or 2 times. There are only two choices, PB2 will toggle between them. Press PB2 until the FLASH-COUNT corresponds to the desired Reversing Valve logic configuration.
9. Press PB3 to exit the configuration tables and return to normal operation. Reconnect terminal block J1 if it was removed.

NOTE: At this time the node is running in the configuration last indicated by D4 and D3 in each of the configuration property tables. Changes are saved in non-volatile memory.

CONFIGURATION PROPERTY TABLES:

CONTROL MODE CONFIGURATION — TABLE 1				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	PTAC * (Factory Default)	1	1	Fan will speed-hunt in AUTO. Fan speed 1, 2 or 3 may be selected to run the fan continuously. (SEE LOGIC TABLE 1.)
2	PTAC (ENERGY SAVER)	1	2	Fan will speed-hunt in AUTO. Selecting Fan speed 1, 2 or 3 will cycle the fan with each call for heating or cooling at that speed. Continuous fan not allowed (SEE LOGIC TABLE 2.)
3	PTHP (HEAT PUMP)	1	3	Fan will speed-hunt in AUTO. Fan speed 1, 2 or 3 may be selected to run the fan continuously. (SEE LOGIC TABLE 3.)
4	FAN COIL (NO FLOW VALVE)	1	4	Fan will speed-hunt in AUTO. Selecting Fan speed 1, 2 or 3 will cycle the fan with each call for heating or cooling at that speed. Continuous fan not allowed (SEE LOGIC TABLE 4.)
5	FAN COIL (FLOW VALVE)	1	5	Fan will speed-hunt in AUTO. Fan speed 1, 2 or 3 may be selected to run the fan continuously at that speed. (SEE LOGIC TABLE 5.)

* Factory default setting.

SHORT-CYCLE CONFIGURATION — TABLE 2				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	Short Cycle Active * (Factory Default)	2	1	Y (Compressor) control line is held off for 3-minutes after a compressor run cycle or upon power up. In heat pump mode the W control line is delayed with Y.
2	Short Cycle In-active	2	2	Y (Compressor) control line is allowed to energize immediately after a compressor run cycle or upon power up.

* Factory default setting.

MAX FAN SPEED CONFIGURATION — TABLE 3				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	Fan Speed 1 * (Factory Default)	3	1	Fan speed 1 may be selected to run the fan continuously.
2	Fan Speed 1 & 2 Enabled	3	2	Fan will speed-hunt in AUTO (see page 1 foot note). Fan speed 1 or 2 may be selected to run the fan continuously.
3	Fan Speed 1, 2 & 3 Enabled	3	3	Fan will speed-hunt in AUTO (see page 1 foot note). Fan speed 1, 2 or 3 may be selected to run the fan continuously.

* Factory default setting.

NOTE: Table 4-1 applies to firmware versions 2.25 and lower (see Figure 1 for label location)

OCCUPANCY MODE CONFIGURATION — TABLE 4-1				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	Disabled * (Factory Default)	4	1	System does not respond to unoccupied status conditions.
2	Sensor detection method: Contact Closure = Unoccupied	4	2	System recognizes an unoccupied state by a contact closure on Input #1.
3	Thermostat detection method: Key press Activity = Occupied	4	3	System recognizes occupancy by thermostat key press activity. If no key press activity for occupancy timeout period system goes unoccupied. Defaults to occupied status upon power up reset.

* Factory default setting.

D3 will flash in normal operation when the node goes into the unoccupied state.

NOTE: Table 4-2 applies to firmware versions 2.26 and higher (see Figure 1 for label location)

OCCUPANCY MODE CONFIGURATION — TABLE 4-2				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	OFF	4	1	System does not respond to unoccupied status condition.
2	2 °F drift from set point Contact Closure = Unoccupied	4	2	Temperature will drift 2-degrees (down in HEATING, up in COOLING) from users set point when an unoccupied condition is in effect.
3	4°F drift from set point Contact Closure = Unoccupied	4	3	Temperature will drift 4-degrees (down in HEATING, up in COOLING) from users set point when an unoccupied condition is in effect.
4	6°F drift from set point * Contact Closure = Unoccupied	4	4	Temperature will drift 6-degrees (down in HEATING, up in COOLING) from users set point when an unoccupied condition is in effect.
5	8°F drift from set point Contact Closure = Unoccupied	4	5	Temperature will drift 8-degrees (down in HEATING, up in COOLING) from users set point when an unoccupied condition is in effect.
6	10°F drift from set point Contact Closure = Unoccupied	4	6	Temperature will drift 10-degrees (down in HEATING, up in COOLING) from users set point when an unoccupied condition is in effect.

* Factory default setting.

D3 will flash in normal operation when the node goes into the unoccupied state.

NOTE: Table 4-3 applies to firmware versions 3.4 and higher (see Figure 1 for label location)

OCCUPANCY MODE CONFIGURATION — TABLE 4-3				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	OFF	4	1	System does not respond to unoccupied status condition or a contact closure on Input terminal #1.
2	3 °F drift from nominal 72°F Contact Closure = Unoccupied	4	2	Temperature will drift 3-degrees (down in HEATING, up in COOLING) from 72° when unoccupied condition is in effect.
3	6 °F drift from nominal 72°F * Contact Closure = Unoccupied	4	3	Temperature will drift 6-degrees (down in HEATING, up in COOLING) from 72° when unoccupied condition is in effect.
4	9 °F drift from nominal 72°F Contact Closure = Unoccupied	4	4	Temperature will drift 9-degrees (down in HEATING, up in COOLING) from 72° when unoccupied condition is in effect.
5	12 °F drift from nominal 72°F Contact Closure = Unoccupied	4	5	Temperature will drift 12-degrees (down in HEATING, up in COOLING) from 72° when unoccupied condition is in effect.
6	15 °F drift from nominal 72°F Contact Closure = Unoccupied	4	6	Temperature will drift 15-degrees (down in HEATING, up in COOLING) from 72° when unoccupied condition is in effect.

* Factory default setting.

D3 will flash in normal operation when the node goes into the unoccupied state.

OCCUPANCY TIMEOUT CONFIGURATION — TABLE 5				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	2 Minute Delay *	5	1	System responds to an unoccupied status condition (contact closure on Input channel 1) within 2-minutes.
2	1 Hour Delay	5	2	System responds to an unoccupied status (contact closure on Input channel 1) 1-hour after condition is sensed.
3	4 Hour Delay	5	3	System responds to an unoccupied status (contact closure on Input channel 1) 4-hour after condition is sensed.
4	8 Hour Delay	5	4	System responds to an unoccupied status (contact closure on Input channel 1) 8-hours after condition is sensed.
5	16 Hour Delay	5	5	System responds to an unoccupied status (contact closure on Input channel 1) 16-hours after condition is sensed.
6	24 Hour Delay	5	6	System responds to an unoccupied status (contact closure on Input channel 1) 24-hours after condition is sensed.

* Factory default setting.

REVERSING VALVE LOGIC — TABLE 6				
		D4	D3	
	CONFIGURATION	FLASH COUNT	FLASH COUNT	DESCRIPTION
1	B - Reversing Valve Logic *	6	1	Heat pump mode: Reversing valve output active in call for HEATING.
2	O - Reversing Valve Logic	6	2	Heat pump mode: Reversing valve output active in call for COOLING.

* Factory default setting.

CONTROL LOGIC TABLES

		PTAC Mode (Standard)					
Output		Off	Cooling Fan Auto	Cooling Fan 1, 2 or 3	Heating Fan Auto	Heating Fan 1, 2 or 3	
CONTROL OUTPUTS TABLE	G1 FAN 1	CONTINUOUS FAN ALLOWED	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	
	G2 FAN 2	CONTINUOUS FAN ALLOWED	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	
	G3 FAN 3	CONTINUOUS FAN ALLOWED	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	
	O B	Rev Valve	OFF	OFF	OFF	OFF	OFF
	W (HTG)		OFF	OFF	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	Y (COMP)		OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	OFF	OFF

Y Terminal (COMP) short-cycle delay = 3-minutes. (D5 LED will light during the short-cycle delay period.)
 Y terminal will remain active for a minimum of 3-minutes unless the user manually ends a call for cooling.

Logic Table 1

		PTAC Mode (Energy Saver)					
Output		Off	Cooling Fan Auto	Cooling Fan 1, 2 or 3	Heating Fan Auto	Heating Fan 1, 2 or 3	
CONTROL OUTPUTS TABLE	G1 FAN 1	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	
	G2 FAN 2	OFF	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	
	G3 FAN 3	OFF	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	
	O B	Rev Valve	OFF	OFF	OFF	OFF	OFF
	W (HTG)		OFF	OFF	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	Y (COMP)		OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	OFF	OFF

Y Terminal (COMP) short-cycle delay = 3-minutes. (D5 LED will light during the short-cycle delay period.)
 Y terminal will remain active for a minimum of 3-minutes unless the user manually ends a call for cooling.
 Fan will not operate by itself. Fan will only operate during a call for heating or cooling.

Logic Table 2

		P T H P Mode (Heat Pump)				
Output		Off	Cooling Fan Auto	Cooling Fan 1, 2 or 3	Heating Fan Auto	Heating Fan 1, 2 or 3
CONTROL OUTPUTS TABLE	G1 FAN 1	CONTINUOUS FAN ALLOWED	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	G2 FAN 2	CONTINUOUS FAN ALLOWED	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	G3 FAN 3	CONTINUOUS FAN ALLOWED	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	O / B Rev Valve	OFF	ON / OFF	ON / OFF	OFF / ON	OFF / ON
	W (HTG)	OFF	OFF	OFF	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	ON $\geq 2^\circ$ OFF $\leq 0^\circ$
	Y (COMP)	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$

Logic Table 3

Y Terminal (COMP) short-cycle delay = 3-minutes. (D5 LED will light during the short-cycle delay period.)
 W Terminal (2nd stage Aux heat) short-cycle delay = 3-minutes. (D5 LED will light during the delay period.)
 Y and W terminal (if called) remain active for a minimum of 3-mins unless user ends call for heating or cooling.
 O/B Terminal (reversing valve) O logic = active in cooling. B logic = active in heating.

		Fan Coil Mode (without Valves)				
Output		Off	Cooling Fan Auto	Cooling Fan 1, 2 or 3	Heating Fan Auto	Heating Fan 1, 2 or 3
CONTROL OUTPUTS TABLE	G1 FAN 1	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	G2 FAN 2	OFF	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	G3 FAN 3	OFF	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	O / B Rev Valve	OFF	OFF	OFF	OFF	OFF
	W (HTG)	OFF	OFF	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	Y (COMP)	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	OFF	OFF

Logic Table 4

Fan will not operate by itself. Fan only operates during a call for heating or cooling.
 Fan coil with no valves application only uses fan G1 – G3 outputs. Terminals Y, W and O are not used.

		Fan Coil Mode (with Valves)				
Output		Off	Cooling Fan Auto	Cooling Fan 1, 2 or 3	Heating Fan Auto	Heating Fan 1, 2 or 3
CONTROL OUTPUTS TABLE	G1 FAN 1	CONTINUOUS FAN ALLOWED	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	G2 FAN 2	CONTINUOUS FAN ALLOWED	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 2^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	G3 FAN 3	CONTINUOUS FAN ALLOWED	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN	ON $\geq 3^\circ$ OFF $\leq 0^\circ$	CONTINUOUS FAN
	O / B Rev Valve	OFF	OFF	OFF	OFF	OFF
	W (HTG)	OFF	OFF	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$
	Y (COMP)	OFF	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	ON $\geq 1^\circ$ OFF $\leq 0^\circ$	OFF	OFF

Y terminal is used for cooling flow valve – No short-cycle delay imposed.
 W terminal is used for heating flow valve.

Logic Table 5

IMPORTANT NOTES:

1.) The model 12200A control node factory defaults to fan speed 1. If your application requires 2 or 3 fan speeds, be sure to select the number needed as described in the Fan Speed Configuration table above. Otherwise, the system will only energize **G1**. Fan speed-hunting and manually selecting higher fan speeds at the thermostat will not cause **G2** or **G3** to energize if the 12200A control node is not enabled to support them.

2.) When an occupancy mode is enabled (see Occupancy Mode Configuration Table 4), D3 will flash to indicate when the node has gone into the unoccupied state.




Figure 1

NOTES:

- 1.) D5 ON indicates a 3 minute short-cycle delay period is active.
- 2.) Use form A dry contact closure for input terminals 1 & 2
- 3.) D3 flashing in normal operation mode indicates the node has gone into an unoccupied state.
- 4.) Output 1 — 6 switches 24vac (R terminal potential) @ 0.30 amps each max.
- 5.) This device should be powered with a Class 2, U.L. listed transformer.
- 6.) Wiring should conform to all national and local electrical codes.
- 7.) See setup table and configuration instructions in this manual for setup options.

MODEL 12200A PTAC CONTROL NODE — COAXIAL ANTENNA

The model 12200A control node standard antenna option is a 1-meter long flexible coaxial cable. One end is permanently connected at the circuit board. Approximately 3” of the outside jacket and shield are striped back at the free end — this is the actual antenna. The coaxial antenna option allows the installer to mount the circuit board where most appropriate and secure, while positioning the antenna in the most optimum position possible. Sheet metal, control boxes, ductwork, pipes and other electrical wires can interfere with RF signals to and from the control node. For best performance, installers should location the antenna away from such shielding material to the extent possible. In PTAC equipment, the antenna is often located in front of the indoor coil, between the coil and the PTAC cover if the cover is plastic or near the makeup air opening at the bottom of the unit if it is metal. As is the case with any RF system, antenna placement and orientation is important. If you experience difficulty maintaining a reliable RF link with your thermostat, try relocating the node antenna, ensuring it is not blocked by or resting against sheet metal, pipes or wires.




Figure 2 – Model 12200A PCB with Coaxial Antenna